

読み取り音・起動音設定

【起動音設定】

Shut down startup beep



Open startup beep (default)



【読み取り音設定】

Good read beep on




Good read beep off (default)



Volume low



Volume high (default)



Low pitch



Middle pitch (default)



High pitch



Tone long (default)



Tone pip

